

How Do You Mark Storm Drains?

1. It's simple.
2. After you have received permission from the Environmental Affairs Department (EAD) and you have received your Storm Drain Marker kit from EAD find some storm drains and START GLUEING.
3. Read the information in your storm drain marking kit. It should contain the number of markers you requested, a sufficient amount of epoxy, and directions on how to apply the storm markers. A shortened version of the directions follow.
- 4.

Select a surface that is flat. Clean the surface of the concrete or metal where you will apply the marker with a wire brush. The surface must be clean, dry, and free of loose debris. Remove any foreign material like debris, old paint, and oil because this will affect the adhesion of the epoxy.



5. Apply the epoxy from a squeeze tube (provided) in a spiral on the back of the storm drain marker. Start 1/8 inches in from the outside edge and apply an even bead around the entire edge and then work to the center. (We recommend that you wear plastic gloves and do not expose the epoxy to heat, sparks, your skin, your eyes, or your nose. Avoid breathing the vapors of the epoxy. Do your curb marking out-of-doors!).

6 Place the marker on the application surface. Push down hard with a twisting motion forcing epoxy out from the edge. It is important that the entire edge of the marker is sealed to the application surface.



7. Wash any skin that contacts the epoxy with soap and water.